



TITLE
 AUTO MODE CONNECTIONS AT
 COMPUTER SKT11 WHEN START
 ADDRESS PLUG OR PROGRAM
 LOADING UNIT IS CONNECTED

C14